

⚠ WARNINGS AND CAUTIONS

Important: ALWAYS be sure to disconnect power before re-lamping or wiring the fixture. Read these instructions completely before starting installation.

To avoid the risk of fire and/or shock fixture must be installed in compliance to national and local electrical and building codes.

If an existing fixture is being replaced take special notice of which wires were connected in the outlet box.
DO NOT SEPARATE ANY WIRES THAT MAY BE EXISTING IN THE JUNCTION BOX
DO NOT DAMAGE THE INSULATION OF JUNCTION BOX WIRES.

In Regular circumstances the BLACK wire will be "live", WHITE will be "neutral" and GREEN or BARE COPPER will be "ground". In older buildings it is always good practice to reconfirm the polarity of the wiring.

NOTICE

- The important safeguards and instructions outlined in this sheet cannot cover all possible conditions and situations that may occur. It must be understood that caution and certain care factors must be followed. These instructions are provided for your safety and we highly recommend that a licensed, trained electrician install this unit.
- This fixture is designed to be mounted on a correctly installed standard round or octagon box OR through a wiring box with a plaster frame. The box must be securely mounted to the structure of the building. The crossbar and hardware supplied should be used, directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture.

ASSEMBLY INSTRUCTIONS

Step 1

Remove the mounting crossbar (1c) from within the canopy (2a) by loosening the mounting collar nut (2b). Attach the mounting crossbar (1c) to junction box (1a), using two junction box screws (1d) (not provided). *For additional support install the anchor screws (1h) through crossbar into ceiling and thread on the supplied finishing nuts (1f)*. Thread the fixture pivots to the designated rods on the crossbar.

Step 2

Determine the desired length the fixture will hang by selecting from the assorted rod sizes supplied (2c). Slide the fixture wire through the rods, mounting collar and canopy. To connect the rods to each other, attach the quick links (2e) to the loop at the end of each rod and close opening to secure. Attach the bottom quick link (2f) to the fixture body (3a) to secure the rod assembly to the fixture frame. Cutdown the extra wire and connect fixture wires to junction box wires using the marrettes provided (1b). (white to white "N", black to black "L", green to green "G").

Step 3

Install the crystal panels (3g) by positioning them over the designated ports on the fixture frame and threading on the decorative nuts provided (3a). Next slide the decorative ring (3f) over the crystal panels and secure by threading the screws provided (3c). Install recommended lamps (3e) (not provided) (referred to the socket label for maximum wattage and type) to fixture sockets (3d). Finally restore power. *If fixture has integrated LED (Lighting Emitting Diodes) lamp installation is not required*

You are now ready to enjoy your fixture.

