Bordeaux

PD502204

WARNINGS AND CAUTIONS

- \cdot Make sure $\ensuremath{\text{POWER}}$ is $\ensuremath{\text{COMPLETELY OFF}}$ at the fuse box
- \cdot Have your fixture installed by a qualified licensed electrician
- \cdot Prepare everything in a clear area
- \cdot Wear gloves at all times during this installation
- \cdot Read instructions carefully before you start assembly
- \cdot Keep this installation sheet for future reference

Please Note:

- · This Alora Mood LED fixture comes with pre-wired LED module(s)
- \cdot Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- · For dimming, an ELV (Electronic Low Voltage) type of dimmer is required
- 120V input

NOTICE

- The important safeguards and instructions outlined in this sheet cannot cover all possible conditions and situations that may occur. It must be understood that caution and certain care factors must be followed. These instructions are provided for your safety and we highly recommend that a licensed, trained electrician install this unit.
- This fixture is designed to be mounted on a correctly installed standard round or octagon box OR through a wiring box with a plaster frame. The box must be securely mounted to the structure of the building. The crossbar and hardware supplied should be used, directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture.

ASSEMBLY INSTRUCTIONS

Step 1

Remove fixture from its original package.

Step 2

Separate mounting plate (1c) from canopy (2a) by removing decorative nuts (2c).

Step 3

Align mounting plate screws (1d) to desired orientation, and then attach mounting plate (1c) to electrical junction box (1a) using junction box screws provided (1e) in hardware package.

Step 4

To change fixture height, push and hold wire gripper (2g), slide wire to desired length and then release wire gripper (2g) to secure.

Step 5

Make proper electrical connections (**black** to **hot** "L", **white** to **neutral** "N", **ground** to **"GND"**) with wire nuts (1b) provided in hardware package.

Step 6

Align and insert mounting plate screws (1d) through holes on canopy (2a), secure with decorative nuts (2c).

Step 7

Secure bottom fixture (3b) to top fixture (3a) by threading clockwise.

Step 8

Fine tone wire length if necessary, by push and hold wire gripper (2g) and then adjust wire to desired length.

You are now ready to enjoy your fixture.



P. 1.855.855.8926
CANADA: 19054 28th Ave., - Surrey, BC V3Z 6M3
USA: 3035 E. Lone Mountain Rd. - Las Vegas, NV 89081
www.aloramood.com
20220328

