A WARNINGS AND CAUTIONS

- \cdot Prepare everything in a clear area
- · Read instructions carefully before you start assembly
- · Keep this installation sheet for future reference

Please Note:

 For your safety this lamp is outfitted with a polarized plug (one blade is wider than the other). If the plug does not fit securely into the outlet, do not force it - contact a licensed electrician. The plug can be used with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

 This lamp comes with all wires connected. When unpacking, be careful not to pull the electrical wire as damages may occur. Do not connect the fixture to power until fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb.

· 120V input

NOTICE

 The important safeguards and instructions outlined in this sheet cannot cover all possible conditions and situations that may occur. It must be understood that caution and certain care factors must be followed. These instructions are provided for your safety and we highly recommend that a licensed, trained electrician install this unit.

ASSEMBLY INSTRUCTIONS

Step 1

Remove fixture from its original package.

Step 2

Install the recommended lamp (1d) (not provided) (referred on the socket label for maximum wattage and type) to fixture socket.

Step 3

Attach lamp harp (1c) into lamp harp shoulders (1e), followed by shade (1b) and secure with decorative finial (1a) by threading clockwise.


Step 4

Insert plug (2a) into outlet.

Step 5

Use switch (2b) to turn ON/OFF.

You are now ready to enjoy your fixture.





P. 1.855.855.8926
CANADA: 19054 28th Ave., - Surrey, BC V3Z 6M3
USA: 3035 E. Lone Mountain Rd. - Las Vegas, NV 89081
www.aloramood.com
20230109